


If you have previously mounted a VESA plate or the plastic cap on top of the column, you must remove those items before proceeding.

1.



2.

